



<b>PART NO.</b>	<b>DESCRIPTION</b>	<b>PART NO.</b>	<b>DESCRIPTION</b>
SR-2-01	NOSEPIECE	SR-2-45	O-RING
SR-2-02	O-RING	SR-2-46	AIR INTERFACE
SR-2-03	NOSEPIECE CASING	SR-2-47	TIE RING
SR-2-04	O-RING	SR-2-48	AIR TUBE
SR-2-05	JAW HOUSING	SR-2-49	REGULATABLE BUTTON
SR-2-06	JAW (1set=3pcs)	SR-2-50	RETAINING SCREW
SR-2-07	PUSHER	SR-2-51	VACUUME VALVE
SR-2-08	WASHER	SR-2-52	O-RING
SR-2-09	JAW PUSHER SPRING	SR-2-53	TAPPING SCREW
SR-2-10	LOCK RING	SR-2-54	AIR VALVE BODY
SR-2-11	HOUSING	SR-2-55	AIR VALVE RING
SR-2-12	POLYURETHANE RING	SR-2-56	O-RING
SR-2-13	SET NUT	SR-2-57	AIR VALVE BASE
SR-2-14	POLYURETHANE RING	SR-2-58	SUBORDINATE TUBE
SR-2-15	O-RING	SR-2-59	O-RING
SR-2-16	VACUUM SLEEVE	SR-2-60	CONNECTING BASE
SR-2-17	SEALING PLASTIC HOUSING	SR-2-61	O-RING
SR-2-18	SEALING RING	SR-2-62	ON/OFF ASSEMBLY w/ plastic air inlet tub
SR-2-19	HEAD ASSEMBLY	SR-2-63	AIR VALVE ROD
SR-2-20	LIP SEAL	SR-2-64	SCREW PLUG
SR-2-21	RETAINING NUT	SR-2-65	SILENCER
SR-2-22	O-RING	SR-2-66	CYLINDER COVER
SR-2-23	U-RING	SR-2-67	O-RING
SR-2-24	PRINCIPAL AXIS UNIT	SR-2-68	BOLT
SR-2-25A	RESTORE SPRING	SR-2-69	LOCK NUT
SR-2-26	O-RING	SR-2-70	BUFFER
SR-2-27	U-RING	SR-2-71	U-RING
SR-2-28A	END CAP	SR-2-72	O-RING
SR-2-30A	STEM COLLECTOR ADAPTOR	SR-2-73	AIR TUBE PISTON
SR-2-32	O-RING	SR-2-74	PISTON RING
SR-2-33	STEM COLLECTOR OUTER	SR-2-75	TRANSFER TUBE
SR-2-34	STEM COLLECTOR BODY	SR-2-76	PISTON ROD
SR-2-35	RETAINING NUT	SR-2-77	CYLINDER PISTON
SR-2-36	SILENCER	SR-2-78	O-RING
SR-2-37	STEM COLLECTOR END CAP	SR-2-79	BOLT
SR-2-38	SILENCER	SR-2-80	O RING
SR-2-39	SILENCER CAP	SR-2-81	CYLINDER
SR-2-40	HANDLE (LEFT)	SR-2-82	BASE COVER
SR-2-41	HANDLE (RIGHT)	SR-2-83	BONDED SEAL
SR-2-42	TRIGGER	SR-2-84	SEAL SCREW
SR-3-43	TRIGGER VALVE	SR-2-85	HOOK
SR-2-44	ON/OFF BASE		